


Pro**Meister**



User Guide

Produced in Taiwan for
Bileko Car Parts AB
P.O. Box 542
S-645 25 Strängnäs, Sweden
Tel: +46 771 72 00 00
www.promeister.com



Multi-Function Automotive Tester

Multifunktionstester
Multifunktionstestare
Multifunksjonstester

Multifunktionstester
Monitoimitesteri


Art. Nr: PT8111

RVNR-01

Product Specifications


1. Power Source: 12-24V DC System
2. DC Voltage Measurement Range: 0-70V
3. DC Current Measurement Range: 0-5A
4. Frequency Measurement Range: 0-100KHz (Square Wave)
5. Resistance Measurement Range: 0-200K Ω
6. Working Temperature: 0-50°C
7. Storage Temperature: -10-60°C
8. Working Humidity: $\leq 85\%$

Product Description



Product Description


- 1 Screen
- 2 Illumination
- 3 Polarity Indication Light
Positive: Red
Negative: Green
- 4 Testing Probe
Available to take off
- 5 Power Providing Switch
- 6 Mode Button
 - a. Short Press: To switch the measurement function
 - b. Long Press for 3 seconds: To switch on & off the illumination during voltage measurement.
 - c. Long Press for 3 seconds: To switch between max & min voltage value and frequency measurement during AC measurement.
- 7 Fuse Box Cap
Open it to change the fuse
- 8 Fuse
Fixed auto-recover fuse is 5A, replaceable fuse can be any
The tester will use the smallest value to protect the circuit
For example, if Fixed auto-recover fuse is 5A, and replaceable fuse is 10A, the current limitation will be 5A.
If Fixed auto-recover fuse is 5A, and replaceable fuse is 1A, the current limitation will be 1A.
- 9 Power Clips
- 10 Cigarette Lighter Plug
- 11 Auxiliary Ground Connector
- 12 Accessory
 - d. Connector
 - e. Wire Piercing Probe
 - f. Long Testing Probe
- 13 6m Extension Cable (Optional)



Operation

- Shortly press MODE button to switch function between Voltage, Resistance, Current, Signal Frequency and Voltage.
- Connect the red clip to positive of battery, and black clip to negative of battery.
- Auxiliary ground connector is used to connect with the negative of testing object when it is necessary.

1) DC Voltage Measurement (External Voltage Test)




DC Measurement:


- A. DC Voltage Measurement
- B. Illumination
- C. DC Voltage Value
- D. Voltage Unit

- (a) Short press MODE button to switch function to DC Voltage Measurement.
- (b) Connecting the testing probe and auxiliary ground connector to the two polarity of the testing object. (CAUTION: DO NOT PRESS THE POWER PROVIDING SWITCH DURING THE MEASUREMENT.)
- (c) Read the voltage value from the screen.


2) Signal Frequency And Max/Min Voltage Measurement



- Frequency Mode
- A. Frequency Value
 - B. Frequency Unit



- Max Voltage Mode
- C. Maximum Voltage
 - D. Voltage Unit
 - E. Max Signal




- Min Voltage Mode
- F. Minimum Voltage
 - G. Voltage Unit
 - H. Min Signal

Operation

- (a) Short press MODE button to switch function to Signal frequency and voltage measurement.
- (b) Connecting the auxiliary ground connector to the negative or ground, and probe to the positive or the testing target.
- (c) Read the frequency value from the screen.
- (d) Long press MODE button for 3s to switch to max voltage value display.
- (e) Long press MODE button for 3s again to switch to min voltage value display.
- (f) Long press MODE button f for 3s again to switch to frequency measurement.

3) Resistance Measurement



Resistance Measurement

- A. Resistance Measurement
- B. Resistance Value
- C. Resistance Unit

- (a) In order to prevent electrical hazard, please disconnect the power connection and make sure all capacitor has been discharged before the measurement.
- (b) Short press MODE button to switch function to Resistance Measurement.
- (c) Connecting the testing probe and auxiliary ground connector to the two side of the resistor, and read the value from the screen.
- (d) Continuity Test: If the resistance is less than 30 ohms, the buzzer will buzz.

4) Testing Power Providing


(This function can be activated any time when the "POWER PROVIDING SWITCH has been pressed.)

- (a) Press POWER PROVIDING SWITCH forward, the positive voltage will be sent to the testing probe, and positive polarity indicator will light up (Red Color).
- (b) Press POWER PROVIDING SWITCH backward, the negative voltage will be sent to the testing probe and negative polarity indicator will light up (Green Color).
- (c) The providing voltage value will depend on the supply voltage level. For example, the providing voltage will be 12V as supply voltage is a 12V battery.

Operation


5) DC Current Measurement

Short press MODE button to switch the function to DC Current Measurement.



1.1 Providing Current to External


- Connecting the testing probe to the positive of testing load, and auxiliary ground connector to the negative of testing load. Press the **POWER PROVIDING SWITCH** forward.
- Read the current value from the screen.



Operation

1.2

- Connecting the testing probe to the negative of testing load, and auxiliary ground connector to the ground of the circuit. Press the **POWER PROVIDING SWITCH** backward.
- Read the current value from the screen.



Caution

During the power providing, If the short circuit protection has activated, the PPTC fuse will jump off, and it will self-recover within about 60 seconds. Please do not touch the testing probe when short circuit protection is activated because high temperature generally comes with short circuit.

Accuracy

DC Voltage	0 – 70V ± (2% + 2 digits)
Signal frequency and Voltage	Frequency 0 – 100 KHz ± (1% + 1 digits)
Resistance	0 – 200K ± (5% + 3 digits)
Current	0 – 5A ± (3% + 10 digits)